

**SEAT—FRONT—BACK FOAM PAD IS VISIBLE
ABOVE SEAT PIVOT POINT**

**Article No.
90-19-7**

MERCURY: 1991 CAPRI

ISSUE

The front seat back foam pad may show below the seat trim at the inner pivot of the seat. This occurs because the foam was not trimmed properly.

ACTION

Trim the visible part of the seat foam pad. Refer to the following procedure for service details.

1. Roll the seat trim material upward from the seat frame as far as possible, without straining the trim material.
2. Use a sharp cutting blade to carefully remove the visible areas of the seat foam pad.
3. Put the seat trim material back to its original position.

4. Make sure the seat foam pad is not visible.
5. If required, repeat the procedure for the opposite side seat.

OTHER APPLICABLE ARTICLES: None

WARRANTY STATUS: Eligible Under Basic
Warranty Coverage

| OPERATION | DESCRIPTION | TIME |
|------------------|---------------------------------------|-------------|
| 901907A | Trim Foam Pad - One Or Both Sides) | 0.3 Hr. |

DEALER CODING

BASIC PART NO.
7064810

OASIS CODES: 101000, 107000

**CONDITION
CODE**
35